

10/528 005

BEST AVAILABLE COPY




FIGURE 1

BEST AVAILABLE COPY

SINGLE MEDIA




FIGURE 2

10/528005

DOUBLE LAYER MEDIA




FIGURE 3




FIGURE 4

10/528005

EXHIBIT A

Experiment No AF276: Biocidal air filtration membrane project:
Performance of different filtration membrane against BG spores
for 30, 60, 120, 180, 240, 300 and 360 minutes of filtration

| | | BG | |
|--------------|------|-----------|-------------|
| | | 30 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 19.5 | 0.00E+00 | 100.000000% |
| 2M03-01-75C+ | 21.5 | 0.00E+00 | 100.000000% |
| Transweb | 17.5 | 1.75E+01 | 99.99471% |
| C+ | 21.5 | 3.31E+05 | 0.000000% |

| | | BG | |
|--------------|------|-----------|-------------|
| | | 120 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 12.5 | 0.00E+00 | 100.000000% |
| 2M03-01-75C+ | 19.0 | 0.00E+00 | 100.000000% |
| Transweb | 6.5 | 1.30E+01 | 99.99496% |
| C+ | 16.0 | 2.58E+05 | 0.000000% |

| | | BG | |
|--------------|------|-----------|-------------|
| | | 240 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 19.0 | 0.00E+00 | 100.000000% |
| 2M03-01-75C+ | 16.0 | 0.00E+00 | 100.000000% |
| Transweb | 11.0 | 0.00E+00 | 100.000000% |
| C+ | 13.0 | 4.21E+06 | 0.000000% |

| | | BG | |
|--------------|------|-----------|-------------|
| | | 60 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 21.0 | 0.00E+00 | 100.000000% |
| 2M03-01-75C+ | 20.5 | 0.00E+00 | 100.000000% |
| Transweb | 20.0 | 0.00E+00 | 100.000000% |
| C+ | 18.5 | 1.49E+06 | 0.000000% |

| | | BG | |
|--------------|------|-----------|-------------|
| | | 180 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 16.0 | 3.20E+01 | 99.99924% |
| 2M03-01-75C+ | 17.0 | 0.00E+00 | 100.000000% |
| Transweb | 15.0 | 0.00E+00 | 100.000000% |
| C+ | 18.5 | 4.20E+06 | 0.000000% |

| | | BG | |
|--------------|------|-----------|-------------|
| | | 300 min | |
| | | 7.5 LPM | |
| | DL | CFU total | % Reduction |
| 2M03-01-75C+ | 13.5 | 2.70E+01 | 99.99884% |
| 2M03-01-75C+ | 16.0 | 0.00E+00 | 100.000000% |
| Transweb | 9.0 | 0.00E+00 | 100.000000% |
| C+ | 9.0 | 2.32E+06 | 0.000000% |

10/528005

EXHIBIT A

Experiment No AF276: Biocidal air filtration membrane project:
Performance of different filtration membrane against BG spores
for 30, 60, 120, 180, 240, 300 and 360 minutes of filtration

| | DL | BG | |
|--------------|------|----------|-------------|
| | | 360 min | 7.5 LPM |
| 2M03-01-75C+ | 9.0 | 0.00E+00 | 100.000000% |
| 2M03-01-75C+ | 16.0 | 4.80E+01 | 99.99923% |
| Transweb | 14.0 | 0.00E+00 | 100.000000% |
| C+ | 11.0 | 6.20E+06 | 0.000000% |

For BG testsChallenge microorganism: **BG**Aerosol generated by: **6 jets Modified Collision**
Nebulizer

pre-vaporisation: 30 min

Air flow velocity : 7.5 LPM

Nebulizer air flow : 40 PSI

Filtration time : 30 minutes

Collection fluid : 5 ml of PBS with 0.001% antifoam A

Sampling on TSA

| | |
|--------------|--|
| 2M03-01-75C+ | Non-woven + Triosyn + Electrostatic charge |
| Transweb | Electrostatic non-woven without Triosyn |
| DL | Detection Level |

10/528005

EXHIBIT B

Biocidal air filtration membrane project:
Performance of different filtration membrane against MS2 viruses
for 60, 120, 180, 240, 300 and 360 minutes of filtration

| MS2 | | | |
|--------------|-----|-----------|-------------|
| 60 min | | | |
| 7.5 LPM | | | |
| | DL | PFU total | % Reduction |
| 2M03-01-92C+ | 4.2 | 0.00E+00 | 100.000000% |
| Transweb | 4.3 | 1.29E+03 | 99.89250% |
| C+ | 4.0 | 1.20E+06 | 0.000000% |

| MS2 | | | |
|--------------|-----|-----------|-------------|
| 120 min | | | |
| 7.5 LPM | | | |
| | DL | PFU total | % Reduction |
| 2M03-01-92C+ | 4.0 | 0.00E+00 | 100.000000% |
| Transweb | 2.2 | 1.76E+03 | 99.08608% |
| C+ | 4.1 | 1.93E+05 | 0.000000% |

| MS2 | | | |
|--------------|-----|-----------|-------------|
| 180 min | | | |
| 7.5 LPM | | | |
| | DL | PFU total | % Reduction |
| 2M03-01-92C+ | 4.0 | 0.00E+00 | 100.000000% |
| Transweb | 3.5 | 4.23E+03 | 99.94125% |
| C+ | 3.6 | 7.20E+06 | 0.000000% |

| MS2 | | | |
|--------------|-----|-----------|-------------|
| 240 min | | | |
| 7.5 LPM | | | |
| | DL | PFU total | % Reduction |
| 2M03-01-92C+ | 3.9 | 0.00E+00 | 100.000000% |
| Transweb | 3.9 | 8.34E+04 | 99.01882% |
| C+ | 3.9 | 8.50E+06 | 0.000000% |

| MS2 | | | |
|--------------|-----|-----------|-------------|
| 300 min | | | |
| 7.5 LPM | | | |
| | DL | PFU total | % Reduction |
| 2M03-01-92C+ | 4.1 | 0.00E+00 | 100.000000% |
| Transweb | 3.9 | 4.79E+05 | 96.45185% |
| C+ | 4.2 | 1.35E+07 | 0.000000% |

10/528007

EXHIBIT B

Biocidal air filtration membrane project:
Performance of different filtration membrane against MS2 viruses
 for 60, 120, 180, 240, 300 and 360 minutes of filtration

| | DL | MS2 | |
|--------------|-----|----------|-------------|
| | | 360 min | 7.5 LPM |
| 2M03-01-92C+ | 3.8 | 0.00E+00 | 100.000000% |
| Transweb | 3.9 | 4.62E+05 | 97.47541% |
| C+ | 3.9 | 1.83E+07 | 0.000000% |

For MS2 tests

Challenge microorganism: MS2

Aerosol generated by: 6 jets Modified Collision Nebulizer

pre-vaporisation: 30 min

Air flow velocity: 7.5 LPM

Nebulizer air flow: 40 PSI

Filtration time: 30 min, 1, 2, 3, 4, 5 and 6 hours

Collection fluid: 5 ml of PBS with 0.001% antifoam A

Sampling on MS2 media by single layer soft agar

| | |
|--------------|--|
| 2M03-01-92C+ | Non woven + Triosyn + Electrostatic Charge |
| Transweb | Electrostatic Non Woven without Triosyn |
| DL | Detection Level |

10/528 005

EXHIBIT B

**Experiment No AF270: Biocidal air filtration membrane project:
Performance of different filtration membrane against MS2 virus
for 30 minutes of filtration**

| | DL | MS2 | |
|--------------|-----|-------------------|-------------|
| | | 30 min 7.5 LPM | |
| M03-01-69-C+ | 4.3 | 0.00E+00 | 100.000000% |
| M03-01-81-C+ | 4.2 | 0.00E+00 | 100.000000% |
| Transweb | 4.0 | 2.48E+02 | 99.99757% |
| C+ | 3.9 | 1.02E+07 | 0.000000% |

| | |
|--------------|--|
| M03-01-69-C+ | Non woven + Triosyn + Electrostatic Charge |
| Transweb | Electrostatic non-woven without Triosyn |
| DL | Detection Level |

For MS2 tests

Challenge microorganism: MS2

Aerosol generated by: 6 jets Modified Collision
Nebulizer

pre-vaporisation: 30 min

Air flow velocity: 7.5 LPM

Nebulizer air flow: 40 PSI

Filtration time: 30 minutes

Collection fluid: 5 ml of PBS with 0.001% antifoam A

Sampling on MS2 media by single layer soft agar